

Checking NOP on Yanmar 6LP-STE 2-Spring Injectors

1. Leakoff Bolt
2. Leakoff Washers (Denso P/N 949018-1020)
3. Fuel Injector Body
4. 1st Valve Opening Pressure Adjusting Shim
5. 1st Pressure Spring
6. Pressure Pin
7. Spring Seat
8. 2nd Valve Opening Pressure Adjusting Shim
9. 2nd Pressure Spring
10. Pre-Lift Adjustment Spring Seat
11. Intermediate Plate
12. Maximum Lift Adjustment Washer
13. Straight Pin (x2)
14. Nozzle Assembly
15. Nozzle Nut

FOR YOUR INFORMATION

* To check the 2nd opening pressure, remove highlighted parts and replace pre-lift adjustment spring seat with Denso master seat part number 95093-10330.

For additional service information please refer to Denso Service Bulletin number THZ 98-02.

Note: #12 Chamfered side faces nozzle.

